

# VariOS System Update Procedure

## Tools Needed:

1. VariOS Module
2. VariOS Update File
3. USB Compatible Computer
4. USB Caple

## Update Procedure:

***NOTE:** Be sure to install appropriate USB drivers before attempting to update the VariOS. The latest drivers can be downloaded from the VariOS product page at [www.rolandus.com](http://www.rolandus.com).*

1. Connect the VariOS to the computer with a USB cable.
2. While holding down MENU and EXIT, turn the power ON. “\*Update Select from VariOSDrive” should be displayed.
3. Copy the “VARIOS\_UPDATE.rom” file to the “Removable Disk” drive that should be displayed in “My Computer” for a Windows computer, or the “TEST” drive on the Desktop for a Macintosh computer.
4. Properly Eject the “Removable Disk” from the computer.
  - a. On a Windows computer, click “Eject this disk” from “My Computer” when the “Removable Disk” is selected.
  - b. On a Macintosh computer, drage the “TEST” drive to the Trash.
5. Press VALUE to Enter. “From VariOSDrive Push Enter” should be displayed.
6. Press VALUE to process the update.
7. When “Update Complete Please Reboot” is displayed, turn OFF the VariOS.
8. Turn ON the VariOS to return to normal operation.